

Drägerwerk AG & Co.KGaA, 23542 Lübeck

Our reference
PSA-21-120-1

Vulnerability and Incident Reporting
product-security@draeger.com

Dräger Product Security Advisory PSA-21-120-1

Dräger X-Dock Security Vulnerabilities

Legal Notice

This Product Security Advisory is based on all our findings that we had at the time of publication. However, the facts of the case are being reviewed on an ongoing basis and it is possible that this may result in changed assessments or that assessments contained in this advisory may turn out to be incorrect. We also reserve the right to change or revoke any recommendations. In addition, differences may result from the circumstances of the individual case on site. This information is naturally not available to us and has not been taken into account. Dräger can therefore accept no responsibility that the information presented here is conclusive or comprehensively correct for you. Therefore, please check carefully to what extent deviations can arise for your individual case. If necessary, you will be informed about new findings through following advisories.

1 Publication Date

2021-04-30

2 Overview

Security Vulnerabilities have been identified in the X-Dock Firmware. The vulnerabilities can lead to an attacker being able to get root access to the underlying operating system.

The full text of this advisory can be accessed through <https://static.draeger.com/security>.

Drägerwerk AG & Co. KGaA
Moislinger Allee 53-55
23558 Lübeck, Germany
Postal address:
23542 Lübeck, Germany
Tel +49 451 882-0
Fax +49 451 882-2080
info@draeger.com
www.draeger.com
VAT no. DE135082211

Bank details:
Commerzbank AG, Lübeck
IBAN: DE95 2304 0022 0014 6795 00
Swift-Code: COBA DE FF 230
Sparkasse zu Lübeck
IBAN: DE15 2305 0101 0001 0711 17
Swift-Code: NOLADE21SPL

Registered office: Lübeck
Commercial register:
Local court Lübeck HRB 7903 HL
General partner: Drägerwerk Verwaltungs AG
Registered office: Lübeck
Commercial register:
Local court Lübeck HRB 7395 HL

Chairman of the Supervisory Board
for Drägerwerk AG & Co. KGaA
and Drägerwerk Verwaltungs AG:
Stefan Lauer
Executive Board:
Stefan Dräger (chairman)
Rainer Klug
Gert-Hartwig Lescow
Dr. Reiner Piske
Anton Schrofner

3 Affected Products

The following Dräger products are affected by this vulnerability:

- Dräger X-Dock Firmware versions prior to and excluding 03.00.13.

4 How to verify if the product is affected

Open the information screen on the device to review the software version. The software version is also displayed on the screen during device startup.

5 Vulnerability Description

Use of Hard-Coded Credentials (CWE-798)

CVE-2021-28111

Active Debug Code (CWE-489)

CVE-2021-28112

An unused debug port with hard coded credentials was identified on the system.

6 Impact

By extracting and using the hard coded credentials an authenticated remote attacker is able to execute arbitrary code on the system.

7 Severity

The vulnerability can only be exploited in conjunction of CVE-2021-28111 and CVE-2021-28112, therefore, a combined CVSS score is being calculated.

CVSS 3.1 Score

Base Score: 9.8

Severity: High

Vector: CVSS:3.1/AV:N/AC:L/PR:N/UI:N/S:U/C:H/I:H/A:H

8 Remediation

The software has been patched to mitigate the vulnerability. Customers are urged to install the fixed versions as soon as possible:

Drägerwerk AG & Co. KGaA
Moislinger Allee 53-55
23558 Lübeck, Germany
Postal address:
23542 Lübeck, Germany
Tel +49 451 882-0
Fax +49 451 882-2080
info@draeger.com
www.draeger.com
VAT no. DE135082211

Bank details:
Commerzbank AG, Lübeck
IBAN: DE95 2304 0022 0014 6795 00
Swift-Code: COBA DE FF 230
Sparkasse zu Lübeck
IBAN: DE15 2305 0101 0001 0711 17
Swift-Code: NOLADE21SPL

Registered office: Lübeck
Commercial register:
Local court Lübeck HRB 7903 HL
General partner: Drägerwerk Verwaltungs AG
Registered office: Lübeck
Commercial register:
Local court Lübeck HRB 7395 HL

Chairman of the Supervisory Board
for Drägerwerk AG & Co. KGaA
and Drägerwerk Verwaltungs AG:
Stefan Lauer
Executive Board:
Stefan Dräger (chairman)
Rainer Klug
Gert-Hartwig Lescow
Dr. Reiner Piske
Anton Schrofner

- Dräger X-Dock Firmware versions 03.00.13 and later.

In the meantime, customers are advised to disconnect the network connection to devices running affected firmware versions. If data export is needed, customers are advised to use USB export in the meantime (mobile sync).

9 Credit

Dräger would like to thank the ZDI for finding and reporting these vulnerabilities to us!

10 Contact Information

If you have any further questions related to the impact of the vulnerabilities, please contact your designated regional marketing manager. For reporting incidents and potential vulnerabilities in our devices, please refer to <https://static.draeger.com/security> to contact the Product Security team directly.

Drägerwerk AG & Co. KGaA
Moislinger Allee 53-55
23558 Lübeck, Germany
Postal address:
23542 Lübeck, Germany
Tel +49 451 882-0
Fax +49 451 882-2080
info@draeger.com
www.draeger.com
VAT no. DE135082211

Bank details:
Commerzbank AG, Lübeck
IBAN: DE95 2304 0022 0014 6795 00
Swift-Code: COBA DE FF 230
Sparkasse zu Lübeck
IBAN: DE15 2305 0101 0001 0711 17
Swift-Code: NOLADE21SPL

Registered office: Lübeck
Commercial register:
Local court Lübeck HRB 7903 HL
General partner: Drägerwerk Verwaltungs AG
Registered office: Lübeck
Commercial register:
Local court Lübeck HRB 7395 HL

Chairman of the Supervisory Board
for Drägerwerk AG & Co. KGaA
and Drägerwerk Verwaltungs AG:
Stefan Lauer
Executive Board:
Stefan Dräger (chairman)
Rainer Klug
Gert-Hartwig Lescow
Dr. Reiner Piske
Anton Schrofner

11 Revision History

| VERSION | DATE | COMMENTS |
|---------|------------|------------------|
| 1.0 | 2021-04-30 | Initial Advisory |

Drägerwerk AG & Co. KGaA
 Moislinger Allee 53-55
 23558 Lübeck, Germany
 Postal address:
 23542 Lübeck, Germany
 Tel +49 451 882-0
 Fax +49 451 882-2080
 info@draeger.com
 www.draeger.com
 VAT no. DE135082211

Bank details:
 Commerzbank AG, Lübeck
 IBAN: DE95 2304 0022 0014 6795 00
 Swift-Code: COBA DE FF 230
 Sparkasse zu Lübeck
 IBAN: DE15 2305 0101 0001 0711 17
 Swift-Code: NOLADE21SPL

Registered office: Lübeck
 Commercial register:
 Local court Lübeck HRB 7903 HL
 General partner: Drägerwerk Verwaltungs AG
 Registered office: Lübeck
 Commercial register:
 Local court Lübeck HRB 7395 HL

Chairman of the Supervisory Board
 for Drägerwerk AG & Co. KGaA
 and Drägerwerk Verwaltungs AG:
 Stefan Lauer
 Executive Board:
 Stefan Dräger (chairman)
 Rainer Klug
 Gert-Hartwig Lescow
 Dr. Reiner Piske
 Anton Schrofner